

# FIX-OIL

**COLOURLESS treatment that gives an oiled and hydro-repellent effect to clay, natural stoneware, marble, granite...**

## Preparing the substrate:

- ◆ This product's success begins with properly preparing the substrate: if the substrate is dirty or has efflorescence, the final look and condition of the repair will not meet your expectations.
- ◆ The clay, natural stoneware or natural stone must be clean and free of dust, wax, grease, efflorescence...
- ◆ To do this, we can recommend different cleaning systems, depending on the kind of surface to be treated.
- ◆ Ambient temperature must be between +5°C and +35°C.

## What can be expected of FIX-OIL?

- ◆ **FIX-OIL** is a preventive anti-stain protection treatment.
- ◆ **FIX-OIL** leaves the surface with a non-shiny "wet" appearance.
- ◆ **FIX-OIL** is not a varnish: that is to say that, once it has been applied, there is time to clean up the coffee, oil, fizzy drinks, etc., that have fallen on the floor, before it is absorbed by the flooring material.

## Preparing the product:

- ◆ **FIX-OIL** is a ready-to-use product. It is **NOT** necessary to add anything to it.
- ◆ Open the container and apply the liquid with a varnish roller.



Use a varnish roller to apply **FIX-OIL**.



## ATTENTION

**FIX-OIL** should not be used:

- ◆ AT temperatures below +5°C.
- ◆ On tanks or in areas with standing water. (use **FIXAQUA FILM**)
- ◆ For natural, glazed or polished porcelain tiles.



With **FIX-OIL**, floor stains can be prevented.

## COVERAGE:

Acid wash with <b>GRESNET</b> :	25 l/100m <sup>2</sup>
Soapy wash with <b>FIX-SABO</b> :	10 l/100m <sup>2</sup>
<b>FIX-OIL</b> :	0.15-0.18 l/m <sup>2</sup> (depending on the substrate to be treated)



**INTERIOR AND EXTERIOR CLAY TILE:**

**1**  allow to dry for at least 7 days

**2**  If efflorescence appears, wash with 1 part of **GRESNET** and 5 parts of water. Rinse with water.

**3**  Apply two coats of **FIX-OIL**, leaving 24 hours between coats.

**INTERIOR AND EXTERIOR UNGLAZED NATURAL STONEWARE:**

**1**  allow to dry for at least 7 days

**2**  Clean the leftover mortar with 1 part of water and 10 parts of **GRESNET** and then rinse.

**3**  Apply two coats of **FIX-OIL**, leaving 24 hours between coats.

**INTERIOR AND EXTERIOR NATURAL STONE:**

**1**  allow to dry for at least 7 days

**2**  Wash with **FIX-SABO** diluted in water. Rinse with clean water.

**3**  Apply two coats of **FIX-OIL**, leaving 24 hours between coats.

