

# RECRECEM PRE-MIX

**Normal-setting, quick-drying, pre-mixed mortar for producing PLINTHS suitable for laying tiles in 24 hours. Ideal for SWIMMING POOLS.**

## Substrates suitable to take RECRECEM PRE-MIX:

- ◆ Plinths can be made with RECRECEM PRE-MIX on concrete structures, mortars etc.
- ◆ These substrates must be clean, resistant, solid, free of cracks etc.
- ◆ The ambient temperature must be between +5°C and +35°C.

## Preparing the substrate:

- ◆ Making a **PLINTH IN A SWIMMING-POOL** is not difficult, but it requires the application of a **bonding paste** on the concrete of the pool beforehand:
  - this bonding paste is made by mixing 1 part **PRIMFIX** liquid adhesive and 1 part pure Portland cement.
  - spread this paste with a brush, mop etc.
  - **DO NOT ALLOW IT TO DRY.**
  - on the fresh paste, pour the **RECRECEM PRE-MIX** already mixed with the necessary water.
  - even it and make the slopes.



"Wet sand look" mortar



## WARNING

- ◆ **RECRECEM PRE-MIX** must only be mixed with water. Do **NOT** add sand.
- ◆ Do not make plinths with **RECRECEM PRE-MIX** without having first applied bonding paste.
- ◆ **RECRECEM PRE-MIX** is not a mortar for laying tiles.



Bonding paste: **PRIMFIX** + pure Portland.

## Preparing the mortar with RECRECEM PRE-MIX:

- ◆ Mix 2.5 l of water with each 25 kg of **Recrecem Pre-Mix**.
- ◆ Mix in a cement-mixer or with automatic pumping-transport equipment.
- ◆ Mix until the mortar has an appearance similar to "wet sand". If necessary, add a little water, but never too much.

### 1st STEP: Pour onto the FRESH paste

- ◆ The **RECRECEM PRE-MIX** must be poured directly onto the bonding paste while this is still fresh.



Pour directly onto the paste.

### 2nd STEP: Spreading the mortar

- ◆ Work **RECRECEM PRE-MIX** mortar in the same way as any other mortar: it must now be spread uniformly.



Spread uniformly between guides.

### 3rd STEP: Evening

- ◆ As if it were a normal mortar, even the surface in the traditional manner.



Use the normal tools.



Even between guides.

### 4th STEP (optional): Smoothing

- ◆ If you want a finer surface, it can easily be smoothed with a fine trowel.



If necessary, it can also be smoothed.

### CONSUMPTION:

Bonding paste	Portland: 0.2 kg./m <sup>2</sup> PRIMFIX: 0.2 l./m <sup>2</sup>
<b>RECRECEM PRE-MIX</b>	18-20 kg./m <sup>2</sup> per cm of thickness (always depending on the degree of compacting)



Standard-quality plinths.

