

SELLADOR S10

Polyurethane filler of EXTRAORDINARY ELASTICITY: over 800%. Ideal for sealing PVC wall-boxes

Where and how can SELLADOR S 10 be applied?

- ◆ Dilation joints can be made with SELLADOR S 10.
- ◆ Live cracks in concrete can be sealed.
- ◆ PVC - concrete wall boxes can be sealed.
- ◆ The ambient temperature must be between +5°C and +40°C.

Preparing the join between the PVC and concrete:

4 basic steps must be respected:

- ◆ **1st STEP:**
 - use a hammer and scraper to open the entire area around the PVC pipe. Give it an inward "V" shape.
- ◆ **2nd STEP:**
 - in the PVC - concrete join there is a very absorbent element: the concrete. In order to block this absorption, prime the concrete with **IMPRIMACION SELLADOR S10**. Apply the product with a fine trowel, saturating the concrete 100%.
- ◆ **3rd STEP:**
 - allow the **IMPRIMACION** to dry from 1 to 4 hours.
- ◆ **4th STEP:**
 - apply the **SELLADOR S 10** filler, and make it penetrate deeply by pressing it with a spatula.



WARNING

- ◆ Do not use SELLADOR S 10 on wet, dirty, greasy or oily substrates.
- ◆ Do not use SELLADOR S 10 on gypsum panels.
- ◆ Do not use SELLADOR S 10 when you need elasticity and resistance to acids (use SELLAFIX).



It is **ESSENTIAL** to prime well.



Use a special pistol for sausages.

what is SELLADOR S 10 like?

- ◆ SELLADOR S10 is a product which comes ready-to-use. It is grey.
- ◆ SELLADOR S10 is sold in 600 ml packets.
- ◆ SELLADOR S10 must be applied with a specific pistol for these types of packing.

FIRST STEP:

- ◆ Once the area around the pipe has been opened in a "V" shape, prime 100% to saturation with **IMPRIMACION SELLADOR S 10**, using a brush.



Soak the concrete with **IMPRIMACIÓN** primer.

SECOND STEP:

- ◆ Allow the **IMPRIMACION SELLADOR S10** to dry for between 1 and 4 hours before applying the **SELLADOR S 10**.
- ◆ Cut the tip of the **SELLADOR S 10** packet with scissors.



Cut the "sausage" with scissors.

THIRD STEP:

- ◆ Pack the sausage into the pistol with the cut at the tip.
- ◆ Close the pistol with the threaded ring and plastic nozzle, and cut the nozzle diagonally.



Place the "sausage" in the pistol.

FOURTH STEP:

- ◆ Fill the whole area of the PVC pipe with **SELLADOR S 10**, and make the product penetrate deeply.



Make it penetrate deeply.

FIFTH STEP:

- ◆ Press the **SELLADOR S 10** with a spatula so that it bonds perfectly with the PVC and the concrete.
- ◆ Finally, smooth the entire surface.



Smooth the entire surface.

CONSUMPTION:

	For a pipe of diameter:			
	63 mm.	90 mm.	110 mm.	200 mm.
IMPRIMACION SELLADOR S10:	0.04 l	0.05 l	0.06 l	0.09 l
SELLADOR S10: no. of packets	0.4 units.	0.5 huts.	0.6 huts.	0.9 huts.



The finish is safe, flexible and waterproof.

