

SELLADOR S 10

Polyurethane filler of EXTRAORDINARY ELASTICITY: over 800%. Ideal for sealing PVC grommets.

Where and how can SELLADOR S 10 be applied?:

- ◆ Dilation **joints** can be made with **SELLADOR S 10**.
- ◆ **Live cracks** in concrete can be sealed.
- ◆ PVC - **concrete grommets** can be sealed.
- ◆ The ambient temperature must be between +5°C and +40°C.

Preparing the join between the PVC and concrete:

4 basic steps must be respected:

- ◆ **1st step:**
 - use a hammer and scraper to open the entire area around the PVC pipe. Create a "V" shape in the interior.
- ◆ **2nd step:**
 - in the PVC - concrete join there is a very absorbent element: the concrete. In order to block this absorption, prime the concrete with **IMPRIMACIÓN SELLADOR S10**. Apply the product with a fine trowel, saturating the concrete 100%.
- ◆ **3rd step:**
 - allow the **IMPRIMACIÓN** to dry from 1 to 4 hours.
- ◆ **4th step:**
 - apply the **SELLADOR S 10** filler, and make it penetrate deeply by pressing it with a spatula.



WARNING

- ◆ Do not use **SELLADOR S 10** on wet, dirty, greasy or oily substrates.
- ◆ Do not use **SELLADOR S 10** on gypsum panels.
- ◆ Do not use **SELLADOR S 10** when you need elasticity and resistance to acids (use **SELLAFIX**).



It is **ESSENTIAL** to prime well.



Use a special gun for sausages

What is SELLADOR S 10 like?:

- ◆ **SELLADOR S 10** is a product which comes ready-to-use. It is grey.
- ◆ **SELLADOR S 10** is sold in 600 ml sausages.
- ◆ **SELLADOR S10** must be applied with a specific pistol for these types of packing.

FIRST STEP.

- ◆ Once the area around the pipe has been opened in a "V" shape, prime 100% to saturation with **IMPRIMACIÓN SELLADOR S 10**, using a brush.



Soak the concrete with **IMPRIMACIÓN** primer.

SECOND STEP:

- ◆ Allow the **IMPRIMACIÓN SELLADOR S 10** to dry for between 1 and 4 hours before applying the **SELLADOR S 10**.
- ◆ Cut the tip of the **SELLADOR S 10** sausage with scissors



Cut the sausage with scissors.

THIRD STEP:

- ◆ Pack the sausage into the pistol with the cut at the tip.
- ◆ Close the pistol with the threaded ring and plastic nozzle, and cut the nozzle diagonally.



Pack the sausage into the pistol.

FOURTH STEP:

- ◆ Fill the whole area of the PVC pipe with **SELLADOR S 10**, and make the product penetrate deeply.



Make it penetrate deeply.

FIFTH STEP:

- ◆ Press the **SELLADOR S 10** with a spatula so that it bonds perfectly with the PVC and the concrete. Finally, smooth the entire surface.
- ◆ Finally, smooth the entire surface.



Smooth the entire surface.

CONSUMPTION:

	For a pipe of diameter:			
	63 mm	90 mm	110 mm	200 mm
IMPRIMACIÓN SELLADOR S 10:	0.04 l	0.05 l	0.06 l	0.09 l
SELLADOR S 10: no. of sausages	0.4 units	0.5 units	0.6 units	0.9 units



The finish is safe, flexible and waterproof.